# Cristals, tensors, elasticity & piezoelectricity

BY VINCENT LAUDE

Institut FEMTO-ST, MN2S department group « Phononics & Microscopy » 15B avenue des Montboucons F-25030 Besançon

*Email:* vincent.laude@femto-st.fr *Web:* http://members.femto-st.fr/vincent-laude/

# **1** Description of cristals

## **1.1** Properties

The attenuation of elastic waves is smallest for the most ordered states of matter:

- In air (in a gas), the practical limit is a few 100 kHz;
- In water (in liquids), the practical limit is a few 100 MHz;
- With solid-state crystals, the practical limit is a few GHz, at least. The piezoelectric effect can be used to generate and detect elastic waves at those frequencies.

The symmetry of cristals directly dictates the anisotropic properties of elastic waves. Crystals can be classified according to their orientation symmetry. The microscopic symmetry reflects in the macroscopic physical properties.

A cristal is homogeneous: the behaviors of different samples with the same orientation and obtained from the same crystal are identical.

The concept of tensor is the natural mathematical language to describe physical properties and their relations with symmetry.

## **1.2** Crystal array (lattice)

There exist an infinity of nodes, or points that are images in an elementary translation:

 $\overrightarrow{OM} = m \boldsymbol{a} + n \boldsymbol{b} + p \boldsymbol{c}$  with m, n, p indices All nodes have the same atomic environment.



## 1.3 Unit cell

The periodic array (=lattice) can be seen as a stack of unit cells, parallelograms whose vertices are nodes.

A unit cell built from 3 basis vectors is primitive (it contains a single node).





#### Face centered cubic lattice:

an additional node appears at the centre of each face of the cube.

The cubic unit cell is 4 times too wide. The primitive unit cell is a rhomboedron (a polyhedron whose faces are rhombuses).



## 1.4 Basis

A basis is a set of atoms positioned at the nodes of the lattice.

- The basis can be composed of a single atom
  - $\rightarrow$  face centered cubic (fcc): Cu, Ag, Al, Ni, Pt...
  - $\rightarrow$  centered cubic (cc): Li, Na, K, Cr...
- The basis can be composed of a repetition of the same atom
  - $\rightarrow$  diamond: fcc lattice + 1 atom at 1/4, 1/4, 1/4 (Si, Ge...)
- The basis can be composed of different atoms (ZnS, AsGa)





# **2** Orientation symmetry

## 2.1 The 14 Bravais lattices

- The 14 Bravais lattices are the only possible manners to distribute in 3D spaces an infinite array of nodes having the same environment.
- There are conventionally 7 lattice systems.
- They are further separated into possibly 3 lattice centerings:  $\rightarrow$  centered (I)
  - $\rightarrow$  one node on two opposite faces (C)
  - $\rightarrow$  face centered (F)



### 2.2 The 32 point groups (point symmetry classes)

- Adjoining the basis at each node, the overall symmetry of the crystal is possibily reduced.
- A crystal is not necessarily centro-symmetric (piezoelectric crystals, for instance).
- The 32 point groups of crystals imply the anisotropy of the material constants, and hence the anisotropy of propagation velocity (see Section 5).

**3** Examples of structures

### **3.1** Compact hexagonal structure



### **3.2** Face centered cubic (fcc)



## 3.3 ZnO, AlN, CdS: hexagonal system, 6mm symmetry



## 3.4 LiNbO<sub>3</sub> and LiTaO<sub>3</sub>: trigonal system, 3m symmetry



# 4 Introduction to tensors

## 4.1 Linear relations in anisotropic media

Inside a crystal, a cause applied in a given direction generally induces an effect oriented in another direction. For instance, the relation between electrical polarization and electric field is

$$\boldsymbol{D} = \varepsilon \boldsymbol{E} \text{ ou } \begin{pmatrix} D_1 \\ D_2 \\ D_3 \end{pmatrix} = \begin{pmatrix} \varepsilon_{11} \varepsilon_{12} \varepsilon_{13} \\ \varepsilon_{21} \varepsilon_{22} \varepsilon_{23} \\ \varepsilon_{31} \varepsilon_{32} \varepsilon_{33} \end{pmatrix} \begin{pmatrix} E_1 \\ E_2 \\ E_3 \end{pmatrix} \text{ or } D_i = \varepsilon_{ij} E_j$$
(1)

The first two notations make use of vectors and matrices. The last one is tensorial and uses the implied summation convention on repeated indices (or Einstein convention).

 $D_i$  and  $E_j$  are order 1 tensors;  $\varepsilon_{ij}$  is an order 2 tensor. The order is the number of indices.

Giving the components of a tensor is not sufficient in order to determine it. It is furthermore necessary to specify how the tensor transforms in a given transformation of the reference frame: the physical significance does not change when axes are rotated, only the representation of the tensor is changed!

#### 4.2 Reference frame transform matrix

Let  $e_1, e_2, e_3$  and  $e'_1, e'_2, e'_3$  be two reference frames. The components of the new reference frame in the old reference frame form a matrix  $\alpha$  such that (a matrix, not a tensor!)

$$\boldsymbol{e}_{i}^{\prime} = \alpha_{i}^{k} \boldsymbol{e}_{k} \text{ with } \boldsymbol{\alpha} = \begin{pmatrix} \alpha_{1}^{1} \alpha_{1}^{2} \alpha_{1}^{3} \\ \alpha_{2}^{1} \alpha_{2}^{2} \alpha_{2}^{3} \\ \alpha_{3}^{1} \alpha_{3}^{2} \alpha_{3}^{3} \end{pmatrix}$$
(2)

Reciprocally  $\boldsymbol{e}_k = \beta_k^j \boldsymbol{e}'_j$  with  $\alpha_i^k \beta_k^j = \delta_{ij}$  and  $\delta_{ij}$  the Kronecker symbol. If the reference frames are orthonormal then  $\beta = \alpha^T$  (*T*: transposition operator).

The coordinates of a vector obey the transformation law:

$$x_i' = \beta_k^i x_k \text{ with } \boldsymbol{x} = x_k \boldsymbol{e}_k = x_i' \boldsymbol{e}_i' \tag{3}$$

In case the reference frames are orthonormal, then the coordinates of a vector obey the same transformation law as the basis vectors:  $x'_i = \alpha_i^k x_k$ .

### 4.3 Definition of a tensor

- Any scalar physical quantity (temperature, energy, etc.) is invariant of the chosen reference frame:  $f(x_1, x_2, x_3) = f(x'_1, x'_2, x'_3)$ ; it is an order 0 tensor.
- An order 1 tensor (i.e. a vector) transforms in a reference frame change as the basis vectors, or

$$A_i' = \alpha_i^k A_k \tag{4}$$

• An order 2 tensor is a set of 9 components  $A_{ij}$  that transforms according to

$$A_{ij}' = \alpha_i^k \, \alpha_j^l \, A_{kl} \tag{5}$$

• The definition extends smoothly to an arbitrary order, for instance at order 3:

$$A_{ijk}^{\prime} = \alpha_i^l \, \alpha_j^p \, \alpha_k^q \, A_{lpq} \tag{6}$$

- The gradient of a vector,  $\partial A_i / \partial x_k$ , is an order 2 tensor.
- The trace  $A_{ii}$  of an order 2 tensor,  $A_{ij}$ , is an order 0 tensor (a scalar).
- The linear relation between two tensors is also a tensor. For instance  $D_i = \varepsilon_{ij} E_j$  implies that  $\varepsilon_{ij}$  is an order 2 tensor.

# 5 Elasticity

## 5.1 Deformations

Consider a point  $\boldsymbol{x}$  with coordinates  $x_1, x_2, x_3$ . Displacements  $\boldsymbol{u}$  are a function of  $\boldsymbol{x}$ , hence  $u_i(x_j + dx_j) = u_i(x_j) + \frac{\partial u_i}{\partial x_j} dx_j$  to first order.  $\frac{\partial u_i}{\partial x_j}$ , the displacement gradient, is an order 2 tensor.

This gradient is separated into a symmetric part (the strain tensor  $S_{ij}$ ) and an antisymmetric part

$$\frac{\partial u_i}{\partial x_j} = S_{ij} + \Omega_{ij} \text{ with } S_{ij} = \frac{1}{2} \left( \frac{\partial u_i}{\partial x_j} + \frac{\partial u_j}{\partial x_i} \right) \text{ and } \Omega_{ij} = \frac{1}{2} \left( \frac{\partial u_i}{\partial x_j} - \frac{\partial u_j}{\partial x_i} \right)$$
(7)

Only the symmetric part of the displacement gradient actually measures of local volume change of the lattice. The antisymmetric part measures local rotations. The dilation (i.e. the local variation of the volume) is  $S_{ii} = S_{11} + S_{22} + S_{33} = \nabla \cdot \boldsymbol{u}$ , that is the trace of the displacement tensor.

For elastic waves, the diagonal components  $S_{11}, S_{22}, S_{33}$  are linked to longitudinal motion, whereas the non-diagonal components  $S_{ij}$ ,  $i \neq j$  are linked to shear motion.

### 5.2 Stress

Contrary to fluids, shear forces are transmitted through a surface. Three independent forces apply to a surface: a traction-compression force and 2 shear forces.

On the face orthogonal to axis  $x_1$  of an elementary cube, the force per unit surface (i.e. the mechanical traction) is  $T_{11} + T_{21} + T_{31}$  (with similar formulas for faces orthogonal to axes  $x_2$  and  $x_3$ ).

 $T_{ij}$  is a symmetrical order 2 tensor, the stress tensor. For an arbitrary elementary surface with normal l, the mechanical traction is  $T_{ik} l_k$ .



The elastodynamic equation is (with  $f_i$  some body forces)

$$\frac{\partial T_{ik}}{\partial x_k} + f_i = \rho \frac{\partial^2 u_i}{\partial t^2} \tag{8}$$

#### 5.3 Hooke's law

Experiment indicates that the elastic behavior of most solids in the limit of small deformations follows Hooke's law :

$$T_{ij} = c_{ijkl} S_{kl} \tag{9}$$

This amounts to stating that stress is a linear function of strain.

 $c_{ijkl}$  is the elastic tensor, of order 4. It has a priori  $3^4 = 81$  components. The symmetry of both  $T_{ij}$  et  $S_{kl}$ , however, implies

$$c_{jikl} = c_{ijkl} \text{ et } c_{ijlk} = c_{ijkl} \tag{10}$$

There are thus 36 independent components at most. Moreover, it can be shown that the elastic tensor is symmetric,  $c_{ijkl} = c_{klij}$ , hence 21 independent components remain.

As a whole, the actual number of independent components (or independent constants) is a function of the symmetry of the crystal.

### 5.4 Contracted notation (or matrix notation)

Thanks to the symmetry relations we note

$$(11) \longleftrightarrow 1; (22) \longleftrightarrow 2; (33) \longleftrightarrow 3$$
$$(23) = (32) \longleftrightarrow 4; (31) = (13) \longleftrightarrow 5; (12) = (21) \longleftrightarrow 6$$
$$T_{ij} = T_I; c_{ijkl} = c_{IJ}; T_I = c_{IJ}S_J$$
(11)

$$S_1 = S_{11}; S_2 = S_{22}; S_3 = S_{33}; S_4 = 2S_{23}; S_5 = 2S_{31}; S_6 = 2S_{12}$$
(12)

Material	Class	Elastic constants (10 <sup>10</sup> N/m <sup>2</sup> ) $\rho$ (10 <sup>3</sup> kg/m <sup>3</sup> )
cubic ou isotropic		$c_{11}$ $c_{12}$ $c_{44}$
AsGa	$\overline{4}3m$	11.88 5.38 2.83 5.307
$SiO_2$	isotrope	7.85 1.61 3.12 2.203
Si	m3m	16.56 6.39 7.95 2.329
hexagonal		$c_{11}$ $c_{12}$ $c_{13}$ $c_{33}$ $c_{44}$
PZT-4	trans. iso.	13.9  7.8  7.4  11.5  2.6  7.5
ZnO	6mm	$\begin{array}{ cccccccccccccccccccccccccccccccccccc$
trigonal		$c_{11}$ $c_{12}$ $c_{13}$ $c_{33}$ $c_{44}$ $c_{14}$
$Al_2O_3$	$\overline{3}m$	49.7 16.3 11.1 49.8 14.7 -2.3 3.986
LiNbO <sub>3</sub>	3m	$\begin{array}{ cccccccccccccccccccccccccccccccccccc$
quartz $\alpha$ (SiO <sub>2</sub> )	32	8.7 0.7 1.2 10.7 5.8 -1.8 2.648



# 6 Piezoelectricity

## 6.1 Physical origin of piezoelectricity

**Direct piezoelectric effect**: if a stress or strain is applied, an electrical polarization appears (i.e., a non symmetrical deformation of the atomic unit cell and/or of the distribution of bound electrons).

**Inverse piezoelectric effect** (or Lippman effect): An applied electric field induces a stress or strain.

The piezoelectric effect is only observed in non centrosymmetric crystals.

## 6.2 Constitutive relations

Considering the linear regime only, and choosing strain and electric field as the state variables,

$$T_{ij} = c_{ijkl} S_{kl} - e_{kij} E_k \tag{13}$$

$$D_i = e_{ikl} S_{kl} + \varepsilon_{ij} E_j \tag{14}$$

or in contracted notation for the mechanical part

$$T_I = c_{IJ}S_J - e_{kI}E_k \tag{15}$$

$$D_i = e_{iJ}S_J + \varepsilon_{ij}E_j \tag{16}$$

Piezoelectric tensor  $e_{ikl} = e_{iJ}$  is symmetrical vs. the last 2 indices only.

#### 6.3 Quasi-static approximation

As a consequence of piezoelectric coupling, an electromagnetic wave travels along with the elastic wave. Maxwell's equations in a dielectric (or insulator) are :

$$\nabla \times \boldsymbol{E} = -\frac{\partial \boldsymbol{B}}{\partial t} ; \nabla \times \boldsymbol{H} = \frac{\partial \boldsymbol{D}}{\partial t} ; \nabla \cdot \boldsymbol{D} = 0 ; \nabla \cdot \boldsymbol{H} = 0 ; \boldsymbol{B} = \mu_0 \boldsymbol{H}$$
(17)

The involved frequencies are quite small compared to optical waves, resulting in negligible temporal derivatives:

$$\nabla \times \boldsymbol{E} = -\mathrm{i}\omega \boldsymbol{B} \simeq 0 \text{ and } \nabla \times \boldsymbol{H} = \mathrm{i}\omega \boldsymbol{D} \simeq 0$$

This approximation decouples electric and magnetic fields. In addition, as the electric field is irrotational there exists a scalar potential  $\phi$  such that  $E = -\nabla \phi$ . The constitutive relations become

$$T_I = c_{IJ}S_J + e_{kI}\phi_{,k} \tag{18}$$

$$D_i = e_{iJ} S_J - \varepsilon_{ij} \phi_{,j} \tag{19}$$

## 6.4 Matrix representation of constitutive relations

Grouping tensors in equations (15-16) into a table of constants:

<i>c</i> <sub>11</sub>	$c_{12}$	•	•	•	•	$e_{11}$	$e_{21}$	$e_{31}$
$c_{12}$	$c_{22}$	•	•	•	•	$e_{12}$	•	•
•	•	•	•	•	•	•	•	•
•	•	•	•	•	•	•	•	•
•	•	•	•	•	•	•	•	•
$c_{16}$	•	•	•	•	<i>c</i> <sub>66</sub>	$e_{16}$	•	$e_{36}$
$e_{11}$	$e_{12}$	•	•	•	$e_{16}$	$\varepsilon_{11}$	$\varepsilon_{12}$	$\varepsilon_{13}$
$e_{21}$	•	•	•	•	•	$\varepsilon_{12}$	•	•
$e_{31}$	•	•	•	•	$e_{36}$	$\varepsilon_{13}$	•	$arepsilon_{33}$

This representation is quite handy to identify possible couplings given the crystal symmetry, but also in order to represent « material constants » data in a numerical simulation program.



FIG. 3. 14. Composantes des tenseurs élastiques, piézoélectriques, diélectriques suivant les classes de symétrie avec les axes de référence de la figure 2.22. . - nulle : 0 non nulle: composante

La symétrie par rapport à la diagonale principale n'est pas mentionnée. Les nombres de constantes élastiques, piézoélectriques et diélectriques indépendantes sont indiqués  $egales \dot{a} (c_{11} - c_{22})/2 : X$ 9 - opposées : • 0 égales : à droite de chaque ensemble. 1 composantes

(m/T <sup>1</sup> )	53	~	s <sup>23</sup>	560	7,83	8,44	£33	22	26	£3,	25,7	38,1 4,10	521 E33	01 28	
РЕКМІТ (10 <sup>-1</sup>	34	5 <sup>S</sup> 113	650	7,38	7,99	6 <sup>5</sup> 1	20	1 744	511 113	38,9	36,3 3,92	211 73	196		
CONSTANTES PIÉZOÉLECTRIQUES (C/m²) e14 - 0,16				r r	1,14	0,44	633	0	3,64	613	ן ר <u>י</u>	6 <sup>7</sup> 1	e,3	43	
		99 éé	0	15					~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	631	0,2	0 × 0	£32	- 0.3	
	16		_	2	,61	24	631	0	- 26	e11	2,5	1,6 0		4	
		e3	- 5	- 0	0	51	0	ст С	e15	3,7	2,6 0	63	1		
					20	21				e14	0	0,0406	e24	4	
			12	- 0,	0 -	\$1a	0,22	0	611	0	0,171	e15	36		
CLASSE		- 43m	23		trans.	6mm	етт		422	4mm		3т	3т 32		
MATÉRIAUX	Système cubique	Arséniure de gallium (AsGa)	de germanium (Bi <sub>12</sub> GeO <sub>20</sub> )	Système hexagonal	Céramique PZT-4	Oxyde de zinc (ZnO)	(CdS)	Système tétragonal	Paratellurite (TeO <sub>2</sub> )	Titanate de baryum (BaTiO <sub>3</sub> )	Système trigonal	Niobate de lithium (LiNbO <sub>3</sub> )	Tantalate de lithium (LiTaO <sub>3</sub> ) Quartz (SiO <sub>2</sub> )	Système orthorhombique	Niobate de baryum et de sodium (Ra. Na Nh. O )

## 6.5 Boundary conditions

#### Mechanical boundary conditions

- For two rigidly bonded solids, the displacements are continuous at any point of the boundarye  $\Sigma$  between media M and M':  $u_i = u'_i$ . Likewise, the traction is continuous:  $T_{ij}l_j = T'_{ij}l_j$  with  $l_j$  the normal to  $\Sigma$ .
- At a free surface, displacements are unspecified but  $T_{ij}l_j = 0$ .
- At a clamped surface, stresses are unspecified but  $u_i = 0$ .

#### **Electrical boundary conditions**

Within the quasistatic approximation, they are similar to electrostatics.

- At an interface  $\Sigma$ ,  $\phi = \phi'$  and  $E_t = E'_t$  (both the potential and the tangential electric field are continuous).
- If the surface is charged (case of a metal-dielectric interface) then  $(D'_i D_i) \ l_i = \sigma \ (\sigma: \text{ surface charge density})$ . Across two dielectrics, the normal component of D is continuous.
- If the surface is short-circuited (e.g. because a metal thin-film is grounded) then  $\phi = 0$ .

### 6.6 Poynting's theorem and energy balance

Expressing the work of mechanical and electrical forces, Poynting's theorem for piezoelectric media is obtained as:

$$\frac{\mathrm{d}W}{\mathrm{d}t} = \frac{\mathrm{d}}{\mathrm{d}t}(E_c + E_p) + \int_{\Sigma} P_j l_j \,\mathrm{d}s \tag{20}$$

with

- kinetic energy  $E_c = \int e_c \, dV$  and energy density  $e_c = \frac{1}{2} \rho v_i^2$
- potential energy  $E_p = \int e_p \, dV$  and  $e_p = \frac{1}{2} \left( S_{ij} T_{ij} + E_k D_k \right)$
- Poynting's vector  $P_j = -T_{ij}v_i + (\boldsymbol{E} \times \boldsymbol{H})_j$

As in the case of fluids, Poynting's theorem expresses the fact that work performed by internal sources in volume V is partially stored as a combination of kinetic and potential energy and partially radiated through boundary  $\Sigma$ . The flux of Poynting's vector accounts for this radiated power.